




**WB 17X210**  
G.E. Receptacle Assembly  
and Terminal Block - Plastic.



**WB 17X5095**  
G.E. Receptacle Assembly  
and Terminal Block.



**WB 17X5051**  
G.E./Hotpoint Ceramic  
Receptacle. For Original G.E.  
Style Plug-in Burners.




**WB 17X5113**  
G.E./Hotpoint Plastic  
Receptacle. Fits Regular Style  
Burners.



**WB 5X5002**  
G.E./Hotpoint Terminal.



**WB 17X105**  
G.E./Hotpoint Contact Block.  
**WB 2X574 EA**  
G.E./Hotpoint Clips for Blocks.



**WB 23X33**  
G.E./Hotpoint Push Button  
Switch.



**WB 23X5102 (WB 23X40)**  
G.E./Hotpoint Push Button  
Switch 1" Stems.



**WB 21X5243**  
G.E./Hotpoint Push to Turn  
Switch Kit. 1 5/8" Break Off  
Shaft. (5500-212).



**WB 23X5070**  
G.E./Hotpoint  
Switch for 3 Wire Burner  
CW, 1/2" D-Stem Shaft.



**WB 21X5237**  
G.E. Infinite Heat Switch,  
Push to turn, 3/4" Shaft.




**WB 21X5246**  
G.E. Infinite Heat Switch,  
Push to turn, 1" Break off  
Shaft.



**WB 23K5027**  
G.E. Element Control,  
Push to turn, 3/4" Shaft.



**WB 23M24**  
G.E. Element Control, 1500W,  
Push to turn, 3/4" Shaft.



**WB 21X184**  
G.E./Hotpoint Responder  
Switch Use with sensor  
WB 21X5207.



**WB 21X5207**  
G.E./Hotpoint  
Surface Unit Sensor Yellow.  
**WB 21X5054**  
G.E./Hotpoint Surface Unit Sensor White.



**WB 21X162**  
G.E. Responder.



**WB 2X7909**  
G.E. Anti-Tip Kit.